



1. Pls release A & B to unlock the stroller.




2. Step on and lock the supporting,




3. Insert the tube of front wheel into the plastic of front wheel .




4. Press downward, and unfurl the canopy; pull upward and draw the canopy in.




5. Please put the front-tray into the fram.




6. Please pull A to put down the backrest. Please pull B & push A to put up backrest.




7. Pull the directional panel and turn the front wheel directional or turn it in all direction .




8. Step on the brake of the back wheels and lock the stroller.



9. To fit harness:
A Insert both fasteners securely into clasp.
B Adjust strap lengths by sliding buckles.
 Belt and harness should be snug.
 To release harness:
C Squeeze fastener prongs and pull apart.



10. Adjust the stroller to the sitting status, turn over the canopy downwards . Release the locked supporting.



11. Lock the stroller by matching A & B.

Dream On Me Inc.

1532 S Washington Ave

Piscataway Township

NJ 08854

TEL: 732-752-7220

Customer Care: +1 (732) 366-1788

Model No: #453

⚠ **WARNINGS:** never leave child unattended, always keep child in view when in use.

⚠ **WARNING** Avoid serious injury from falling or sliding out.

Always use seat belt.

- The parcels or accessory items, or both, placed on the unit may cause the unit to become unstable.
- The excessive weight may cause a hazardous unstable condition to exist.
- The maximum weight 33 pound.
- The maximum weight 5 pound of the storage basket.
- The maximum weight 2 pound of the canopy basket.
- Do not use stroller near open fire, exposed flame or heaters.
- Do not use stroller if any screws, nuts or bolts are missing or any compartment is damaged.
- Do not wash, if get the urine stain, blood stain, ink stain ... on the stroller, pls clear it by detergent.