

## WARNINGS!

FOR THE SAFETY OF YOUR CHILD, PLEASE READ THE FOLLOWING AND KEEP FOR FUTURE REFERENCE.

NEVER LEAVE CHILD UNATTENDED. ALWAYS KEEP CHILD IN VIEW WHEN IN STROLLER.

AVOID SERIOUS INJURY, ALWAYS USE SEAT BELT. PERIODICALLY CHECK THE RESTRAINT SYSTEM TO MAKE SURE IT IS SECURE.

THIS STROLLER MAY BECOME UNSTABLE IF PARCEL, SHOPPING BAGS OR PURSES ARE PLACED ON OR HUNG ON THE STROLLER.

THIS STROLLER IS TO BE USED BY ONE (1) CHILD ONLY.

ALWAYS MAKE SURE STROLLER IS FULLY OPEN AND LOCKED BEFORE USING.

ALWAYS USE THE BRAKES WHEN STROLLER IS STOPPED.

DO NOT USE STROLLER ON STAIRWAYS OR ESCALATORS.

YOUR STROLLER IS NOT A TOY, DO NOT ALLOW CHILDREN TO CLIMB INTO THE STROLLER UNASSISTED AS STROLLER MAY TIP OVER AND INJURE CHILD.

CARE SHOULD BE TAKEN WHEN FOLDING AND UNFOLDING STROLLER TO PREVENT FINGER ENTRAPMENT.

DO NOT OVERLOAD STROLLER IF STROLLER IS EQUIPPED WITH A BASKET THEN MAXIMUM LOAD OF BASKET IS 10 POUNDS, IF EQUIPPED WITH A POUCH, THEN MAXIMUM LOAD IS 2 POUNDS.

**WARNING:**  
AVOID SERIOUS INJURY. DISCONTINUE USING YOUR STROLLER SHOULD IT BECOME DAMAGED OR BROKEN.

THIS PRODUCT IS NOT INTENDED FOR COMMERCIAL USE.

TO PREVENT SERIOUS INJURY, WHEN MAKING ADJUSTMENTS ON YOUR STROLLER (SUCH AS ADJUSTING SEAT OR HANDLE) BE CERTAIN CHILD'S FINGERS, HANDS AND OTHER BODY PARTS ARE CLEAR OF ANY MOVING PARTS.

## PLEASE NOTE:

STROLLERS ARE NORMALLY USED FOR CHILDREN FROM INFANCY TO 36 MONTHS OF AGE WITH AN APPROXIMATE MAXIMUM WEIGHT OF 40 LBS (18KGS.) OR AN APPROXIMATE HEIGHT OF 38 INCHES (965MM) OR BOTH. DISCONTINUE USE WHEN YOUR CHILD EXCEEDS ANY OF THESE LIMITS.

## CLEANING:

TO CLEAN METAL PARTS, WIPE WITH A DAMP CLOTH AND WIPE DRY.

TO CLEAN VINYL PARTS, WIPE WITH A MILD SOAP AND WATER SOLUTION.

TO CLEAN WOVEN FABRICS, USE AN UPHOLSTERY CLEANER SUCH AS NORMALLY USED ON FURNITURE.

## CARE AND MAINTENANCE:

OIL CASTER BOLTS AND WHEELS AXLES PERIODICALLY REPLACE ANY DAMAGED PARTS IMMEDIATELY.

DUE TO PRESSURE FROM PACKAGING THE STROLLER TIRES MAY HAVE SMALL INDENTURES, THESE INDENTURES WILL SMOOTH OUT AFTER THE STROLLER HAS BEEN UNFOLDED FOR SEVERAL DAYS. IF NECESSARY, DIRECT HOT AIR ONTO THE INDENTURES WITH A HAIR DRYER AS THIS WILL SPEED THE INDENTURES TO ORIGINAL SMOOTHNESS. CAUTION: IF THE STREAM OF HOT AIR IS TOO CLOSE IT WILL DAMAGE THE TIRE PERMANENTLY.

Dream On Me, Inc.  
1532 S Washington Ave  
Piscataway Township  
NJ 08854  
TEL: 732-752-7220  
Customer Care: +1 (732) 366-1788  
Model #455

# ASSEMBLY INSTRUCTIONS


## 455





1

TO OPEN STROLLER



Release the safety latch.




Open stroller.


2

TO ASSEMBLE FRONT / REAR CASTER SET

FRONT WHEEL



assemble the front wheel set to the frame.




- a. washer
- b. wheel
- c. washer
- d. dending-bolt
- e. plastic cap

3

TO USE BRAKES

ALWAYS APPLY BOTH BRAKES TO PARK




4

TO FOLD STROLLER



Folding the stroller by pulling up the folding triggers joint.



Push down on handle and lock safety latch.