


Tandem Stroller



DOM
— FAMILY —

Please read this owner's manual carefully and keep it in a safe place.

Owner's
Manual

Dream On Me Model NO : #456

CLEANING & MAINTENANCE

AVOID SERIOUS INJURY; PLEASE DO A ROUTINE MAINTAINANCE INSPECTION.

1. Never force any folding or adjustable parts.
2. Ensure that all the devices are correctly engaged before use.
3. Regularly lubricate all moving parts with silicon spray only.
4. To clean plastic or cloth surface, use lukewarm water with mild detergent only. To clean metal surface, wipe clean with soft, damp cloth. Do not use abrasives or solvents.
5. Do not keep the stroller in the damp, cold or hot place.
6. Check the folding lock when not using. Please do not leave your stroller outside unprotected.
7. Regularly check unit to ensure no parts are loose or broken.

Owner's Manual

Part list

Frame ×1



canopy ×2



front tray ×1



cup holder ×1



axel ×1



front wheel assy. ×2






rear wheel ×2



How to open and Assemble the stroller

1. Remove the product from packaging.
2. Release the folding latch, see fig.1
3. Unfold stroller by pull the frame apart as shown in fig 2.
4. Attaching the Front Wheels. Insert the front wheel into the tube of the frame until you hear a click. Repeat for other front wheel. Pull to confirm it is assembled securely. See Figure 3.
Removing the front wheels. To release front wheels, press the button (located at the bottom of front leg) and pull wheel off of the frame. See Figure 4.
5. Attaching Rear wheel.
First attach the rear wheel housing on rear legs, until you hear a click, make sure the spring comes out, see fig.5. Then insert the rear wheel on axle, until you hear a click, see fig.6



Keep pressing the button in the center of wheel and pulling then can remove the rear wheel ,see the fig.6A and 6B




6. Attaching the rear canopy on seat using the clip on canopy, See fig.7

7. Insert the front canopy on the canopy holder, See fig.8

8. Attaching the front tray

Insert the metal bar of front tray in housing until you hear a click. Press the button to releae the front tray, see fig.9



Fitting the Harness

⚠ WARNING

- **Never leave child unattended.**
- **Avoid serious injury** from falling or sliding out. Always use seat belt. Check frequently to make sure it is secure. Belts must be threaded exactly as shown.
- Failure to follow these instructions could result in the serious injury or death of your child.

Fitting the harness



Avoid serious injury from falling or sliding out. Always use seat belt. After fastening buckles, adjust belts to get a snug fit around your child.

To attach the harness

Insert both fasteners security into the clasp. See figure 11
Adjust each strap length as needed.

To undo the harness

Press the fastener buckles and pull apart. See figure 10



How to fold the stroller

1. First close the canopy, see fig. 12
2. Pull the levers on both sides up, see fig. 13
3. Push the handle bar forward to fold, using the folding hook to fix it, see fig. 14

FUNCTIONS

How to use the brake

Step down the connect tube to lock stroller, lift it up to release. See fig. 15


the button up then can adjust backrest up, see fig. 17

How to adjust the handle

Press the button to adjust the height of handle
See fig. 18

Front Swivel Locks.

Push the front wheel swivel release lever down until you hear a click. Start pushing stroller and the wheels will automatically lock into place. lift it up, then release. See Figure 19.



WARNING

Failure to follow these warnings and the assembly instructions could result in serious injury or death

1. Adult assembly is required. This stroller contains small parts, which are for adult assembly only. Keep small children away while assembling the stroller.
2. Remove protective material and plastic bags and dispose of them before assembling the stroller.
3. Stroller is suitable for children from 6 to 36 months.
4. Ensure that all locking devices are engaged before use. Check that the stroller or seat attachment devices are correctly engaged before use.
5. Avoid serious injury from falling or sliding out. ALWAYS use seat belt. After fastening buckles, adjust belts to get a snug fit around your child.
6. Stroller is for one child only per seat
7. DO NOT use storage basket to carry children.
8. NEVER lift the stroller by the front tray.

WARNING

Failure to follow these warnings and the assembly instructions could result in serious injury or death

9. ALWAYS set the parking brake when placing child in or removing child from seating unit.
10. Open stroller away from the child before use.
11. DO NOT use the stroller when the road is not smooth. DO NOT keep stroller near hot surfaces or other similar dangerous places.
12. NEVER leave child unattended while in the stroller. DO NOT allow child to crawl out under or over the front tray or stand in the stroller.
13. DO NOT lift stroller with child inside.
14. The backrest should be adjusted by the adult.
15. Any accessories which are not approved by the manufacturer shall not be used.
16. To prevent a hazardous, unstable condition, DO NOT hang or place items on the stroller handle, canopy, or frame.

WARNING

Failure to follow these warnings and the assembly instructions could result in serious injury or death

17. This product is not suitable for running, skating, or other similar activities.
18. ALWAYS use the crotch strap in combination with the waist belt.
19. Follow the washing instructions on the seat pad.
20. Use of the stroller with a child weighing more than 40lbs (18kg) on each seat could be unsafe.
21. To prevent a hazardous, unstable condition, DO NOT place more than 11bs(5kg) in basket.DO NOT place more than 1.7lbs (0.8kg) in the parent tray or cup holder.
22. To prevent the chance of serious burns NEVER place hot liquids in front tray or cup holder.

Dream On Me inc.
1532 S Washington Ave Piscataway TWP NJ 08854
Tel 732-752-7220 Fax 732-752-7221 Made in Xiang Yang, Hu Bei, China