



1. Pls release A & B to unlock the stroller.




2. Step on and lock the supporting.




3. Insert the tube of front wheel into the plastic of front wheel .



4. Press downward, and unfurl the canopy; pull upward and draw the canopy in.




8. Step on the brake of the back wheels and lock the stroller.




7. (1) Use the thumb to press the top plastic piece.  
 (2) Use the forefinger to withstand plastic piece on the below and use two finger to adjust it.  
 First: Sit. Second: half-lie Third: Lie



9. To fit harness:  
**A** Insert both fasteners securely into clasp.  
**B** Adjust strap lengths by sliding buckles. Belt and harness should be snug.  
 To release harness:  
**C** Squeeze fastener prongs and pull apart.



10. Adjust the stroller to the sitting status, turn over the canopy downwards . Release the locked supporting.



11. Lock the stroller by matching A & B.

**Dream On Me Inc.**  
 1532 S Washington Ave  
 Piscataway Township  
 NJ 08854  
 TEL: 732-752-7220  
 Customer Care: +1 (732) 366-1788  
**Model #458**

- ! WARNINGS:** never leave child unattended, always keep child in view when in use.
- ! WARNING** Avoid serious injury from falling or sliding out. Always use seat belt.
- The parcels or accessory items, or both, placed on the unit may cause the unit to become unstable.
  - The excessive weight may cause a hazardous unstable condition to exist.
  - The maximum weight 33 pound.
  - The maximum weight 5 pound of the storage basket.
  - The maximum weight 2 pound of the canopy basket.
  - Do not use stroller near open fire, exposed flame or heaters.
  - Do not use stroller if any screws, nuts or bolts are missing or any compartment is damaged.
  - Do not wash, if get the urine stain, blood stain, ink stain ... on the stroller, pls clear it by detergent.