

Product Introduction

PORTABLE PLAY YARDS

The Uses of this Product

Our product is specially designed for baby's safety, which can protect baby from injuries, such as crush, scald etc. during playing. It is convenient whatever indoor or outdoor.

Product Features

- 1.Easy to operate.
- 2. Light and portable, easy to carry.
- 3. Polygon design, high security.

Product Specifications

Size: L720mm x H 750mm Expanding effictive space $\approx 1 \text{ m}^2$.


The scope of application and maintenance

- 1. Suitable for children's playing and rest, which height not more than 890mm and can't climb out.
- 2. Fabric cover could be removable. Hand wash and air-dry. (Machine wash is not allowed)


Product Introduction

PORTABLE PLAY YARDS


1. Take out from the packaging.



2. Press the button all along until release the rope.




3. Take out from the buggy bag and expand fully, as shown below.



6. Fold up and keep in a dry place, or put it into the buggy bag and keep in a dry place.

5. Slide the button until it is unlocked and then push down.

4. Pull up until it is locked as below shown.



Remove Fabric and Washing Instruction

DREAM ON ME INC.


1532 S WASHINGTON AVE PISCATAWAY TWP NJ 08854

WWW.DREAMONME.COM


EMAIL: INFO@DREAMONME.COM

MADE IN ZHONG SHAN, CHINA


1. Half spread baby playpen, unbutton the snap button



2. Untie the velcro of each iron pipe




3. Press and take out of the triangle button from baby playpen




4. Fabric cover is only for hand wash and air-dry. (Machine wash is not allowed).


Fabric Installation Instruction

PORTABLE PLAY YARDS







2. Buckle snap button A into A, B into B, same do the others.




3. Stick velcro of iron pipe on baby playpen.




4. Put big round hole of triangle button into out-screw of baby playpen bottom, and pull upward of ribbon and fasten (after hearing "pa" voice)



5. Pull the double safety lock up to use it.



List of products



A.Playyard (frame and cover) 1set B.Travel bag

C. Instruction Manual 1pcs



Service assurance

Thank you for your patronage of our products for child safety protection. If you are not satisfied with the product or have any doubt, please call our service hotline:908-791-0555,we will listen to your valuable suggestions and provide satisfactory service for you sincerely.

↑ WARNING

Failure to follow these warnings and the instructions could result in serious injury or death. Please read instruction Manual before set-up. If you misplace your Istruction Manual, NEVER use this product. Contact dealers for a replacement Instruction Manual.

- 1. The Playard, including all rails, must be fully erected prior to use.
- 2. Make sure all latches/buckles are secure/buckled.
- 3. Discontinue use of the product when child is able to climb out or reaches the height of 35 inches (890 mm).
- 4. Child can become entrapped and die when improvised netting or covers are placed on top of product. Never add such items to confine child in product.
- 5. When child is able to pull to a standing position, remove any objects, such as large toys, in playard that could serve as steps for climbing out.
- 6. Aways provide the supervision necessary for the continued safety of your child. When used for playing, never leave child unattended.
- 7. To reduce the risk of SIDS, pediatricians recommend healthy infants be placed on their backs to sleep, unless otherwise advised by your physician.
- 8. Never use this product if there are any loose or missing fasteners, loose joints, broken parts or torn mesh/fabric. Check product before assembly and periodically during use. Contact dealers for replacement parts. Never substitute parts.
- 9. Never use a water mattress with this product.
- 10. This product is only for play, Can not be used to sleep.

⚠ WARNING

SUFFOCATION HAZARD:

Infant can suffocate:

- 1. In gaps between an extra pad and side of the playard.
- 2. In gaps between a mattress too small or thick and product sides.
- 3. On soft bedding
- Never add a mattress, pillow, comforter, or padding.
- 4. Never use plastic shipping bags or other plastic film as mattress covers not sold and intended for that purpose. They can cause suffocation.

STRANGULATION HAZARD:

- 1. Strings and cords can cause strangulation! Keep strings and cords away from child.
- 2. NEVER place product near a window where cords from blinds or drapes can strangle a child.
- 3. NEVER hang strings on or over the playard.
- 4. NEVER place items with a string around a child's neck, such as hood strings, pacifier cords, etc.
- 5. NEVER attach strings to toys.
- 6. To avoid danger or suffocation keep this buggy bag away form babies and children.

PLAYARD SET-UP:

- 1. Keep fingers clear of folding mechanism during folding and unfolding.
- 2. Keep all children away from the playard during assembly. (sides not
- 3. Always set up playard on a flat, level surface. Check floor/ground surface underneath playard floor to assure that it is clear of any objects that may injure your child. Insure surface is suitable for your child to play on.

TO FOLD PLAYARD:

- 1. Unbuckle all latches.
- 2. Hold two corners and pull up and walk towards center of playard.





1532, S. Washington Avenue Piscataway, NJ 08854 E-mail: info@dreamonme.com

www.dreamonme.com

Follow us on

@dreamonmeinc @dreamonmeinc to get your nursery featured on our social media.

Enter our monthly giveaway!

Chat with us!

Simply scan the QRcode to register. For any questions or concerns or feedback.













